

F1G. 2 CPU 13 AUDIO INPUT SYSTEM -36 NETWORK TRANSMISSION-FIFO NETWORK RECEPTION FIFO AUDIO OUTPUT SYSTEM -40 38 COMPRESSOR **EXPANDER** AUDIO OUTPUT FIFO AUDIO INPUT FIFO 45 A/D CONVERTER - BUFFERS H BUFFERS D/A CONVERTER 46

COLASS SUBCLASS

4070







FIG. 3

FIG. 4



CLASS SUBCLASS

THE CLASS SUBCLASS








FIG. 5





LIAFTSHAN











0.0. F

-160 AUDIO OUTPUT **TASK** -161 NO TASK ENABLED ? YES -162 **AUDIO** YES **OUTPUT FIFO EMPTY** ? NO -164 AUDIO **HARDWARE** NO **READY FOR** PACKET YES -166 MOVE DATA FROM AUDIO **OUTPUT FIFO** TO HARDWARE

-168

RETURN

O.G. FIG.

ChAFISMAN

FIG. 11





FIG. 12

TO CLASS SUBCLASS

FIG. 13



LLG. FIG.

UNAF1SHAH